

---

# ***Operating instructions***

## **Industrial Piston Air Compressors Motor Driven Package**

**C20215-7550**

**Pump Model: LPSS7550**

**Motor: 2 HP**

**Air Tank: C20**

7502 Mesa Road Houston, TX77028

Telephone: (713) 635-6331

E-mail: [service@lapante.com](mailto:service@lapante.com)

Web Site: [www.lapantecompressor.com](http://www.lapantecompressor.com)



Issue: 08/2010

No.

---

| <b>Contents</b>                                | <b>Page</b>   |
|--|---------------|
| <b>Introduction</b> .....                      | <b>1</b>      |
| <b>Unpacking and handling</b> .....            | <b>2</b>      |
| <b>Appropriate use</b> .....                   | <b>4</b>      |
| <b>Symbols used</b> .....                      | <b>5</b>      |
| <b>Symbols used</b> .....                      | <b>5</b>      |
| <b>Symbols on the package</b> .....            | <b>6</b>      |
| <b>Safety guide</b> .....                      | <b>8</b>      |
| <br><b>Technical Data</b> .....                | <br><b>17</b> |
| <b>Specification</b> .....                     | <b>17</b>     |
| <b>Explode drawing</b> .....                   | <b>18</b>     |
| <b>Bom list</b> .....                          | <b>19</b>     |
| <br><b>Section I</b>                           |               |
| <br><b>Pump</b>                                |               |
| <br><b>Installation instruction</b> .....      | <br><b>1</b>  |
| <b>Technical data</b> .....                    | <b>1</b>      |
| <b>Outline drawing</b> .....                   | <b>2</b>      |
| <b>Explode drawing</b> .....                   | <b>3</b>      |
| <b>Bill of material list</b> .....             | <b>4</b>      |
| <br><b>Operation</b> .....                     | <br><b>14</b> |
| <br><b>Parts kits</b> .....                    | <br><b>1</b>  |
| <b>Overhaul Kit</b> .....                      | <b>1</b>      |
| <b>Ring Set</b> .....                          | <b>1</b>      |
| <b>Valve Set</b> .....                         | <b>1</b>      |
| <b>Gasket Set</b> .....                        | <b>1</b>      |
| <b>Disassemble pump</b> .....                  | <b>2</b>      |
| <b>Assemble pump</b> .....                     | <b>2</b>      |
| <br><b>Troubleshooting</b> .....               | <br><b>4</b>  |
| <br><b>Maintenance</b> .....                   | <br><b>7</b>  |
| <b>General</b> .....                           | <b>7</b>      |
| <b>Safety information</b> .....                | <b>7</b>      |
| <b>Check oil level</b> .....                   | <b>8</b>      |
| <b>Check and clean compressor valves</b> ..... | <b>8</b>      |
| <b>Check the safety valve</b> .....            | <b>10</b>     |
| <b>Change oil</b> .....                        | <b>11</b>     |
| <b>Check and change air filter</b> .....       | <b>14</b>     |

---

|  |    |
|--|----|
| Maintenance intervals .....                | 15 |
| List of Maintenance and service work ..... | 16 |

## Section II

### Motor

|                                |   |
|--------------------------------|---|
| Receiving and inspection ..... | 1 |
| Storage .....                  | 1 |
| Installation .....             | 1 |
| Installation-Mechanical .....  | 2 |
| Installation-electrical .....  | 2 |
| Operation .....                | 3 |
| Maintenance .....              | 3 |

## Section III

### Check Valve

|                          |   |
|--------------------------|---|
| General .....            | 1 |
| Safety information ..... | 1 |

## Section IV

### Air Tank

|                              |   |
|------------------------------|---|
| General .....                | 1 |
| Safety information .....     | 1 |
| Check the safety valve ..... | 2 |
| Condensate .....             | 2 |

## Section V

### V-Belt

|                             |   |
|-----------------------------|---|
| General .....               | 1 |
| Safety information .....    | 1 |
| Maintenance intervals ..... | 1 |

## Section VI

### Magnetic Starter

|   |   |
|---|---|
| Safety information .....                      | 1 |
| General .....                                 | 1 |
| Countermeasures for normal malfunctions ..... | 2 |

|  |    |
|--|----|
| List of Maintenance and service work ..... | 16 |
|--|----|

## Introduction

These operating instructions form part of the machine and must be made available to the compressor operating personnel at all times. In order to receive maximum performance and long life from your compressor, the following instructions should carefully read and all points regarding installation and operation of the unit should be noted and observed .careful reading of this manual, prior to connecting anything to the motor or compressor, will pay dividends in long term trouble-free operation.



## Unpacking and Handling



Occasionally damage will occur during shipping. Be sure to carefully inspect the unit before unpacking and after unpacking **BEFORE** you sign the receiver. If any has occurred, document it with the trucking firm immediately. Contact your LAPLANTE representative for assistance.

To move your compressor to its installation site we recommend that you leave the unit on its shipping skid as long as possible. The forks should be extended the width of the compressor and padding should be placed between the compressor and the fork truck boom.

If it is necessary to lift the compressor with a crane, we recommend the use of spreader bar and chains. The spreader bar should be greater than the width of the compressor and padding placed on the edges to prevent chain damage.



### **DO NOT UTILIZE THE PUMP OR DRIVE AS A LIFT POINT**

#### **Procedure for Handling Damaged Shipments**

1. The customer, at the receiving point, **MUST** inspect each shipment for damage.
2. If the shipment is damaged, the customer should so note it on the freight bill.
3. The customer should request an inspector from the freight company to inspect the equipment immediately. It is best to send a confirming letter with the following information:
  - a. Freight bill number.
  - b. Date delivered - shipper's name & address.
  - c. Description of item(s) damaged.
  - d. Description of damage (a Polaroid picture if possible).
  - e. A copy of your invoice for the equipment.
4. After inspection, (before the inspector leaves):
  - a. Get a copy of the inspection report.
  - b. Request the unit be shipped back "free astray".
  - c. Request a credit for the original freight bill.
5. Call the factory and:
  - a. Get a Return Material Authorization (RMA number).
  - b. Give a purchase order for repair. The purchase order should refer to the item and trucker claim.



6. We will accept the shipment back, repair (under normal conditions) and return it within (7) seven working days.
7. We will invoice the customer for the repair, which will then become part of your claim. The Invoice must be presented to the trucking claim department along with their claim form.
8. We suggest if the trucker does not pay within 30 days that you call and / or write the ICC making a formal complaint of poor service. Also advise **LAPLANTE** in writing for follow-up.  
If damage can be repaired at the receiving point, follow Procedure 1, steps 1 through 4a. Repair the unit and make out a detailed invoice to the trucker showing labor hours, labor rate, materials used, and cost of materials.

### Storage

In some cases it may necessary to store the compressor for extended periods of several months before placing the unit in operation. When this is required do the following:

- Cover and seal all machine openings to prevent the entrance of water and dirt.
- Cover all openings in open drip proof motors to prevent the entrance of rodents.
- If the storage conditions are below freezing, drain off the tank, traps, and attendant piping.
- We do not recommend outside storage.
- Cover with a waterproof tarpaulin that can easily be removed for in storage maintenance.
- While in storage, every two to three months rotate the compressor and motor by hand to prevent flat spots on the bearings that will lead to premature failure.
- At the end of the storage period, follow the uncrating and start-up procedures. If the unit has been stored for more than eighteen months you should contact **LAPLANTE** before restarting the compressor.

## Appropriate use

As standard, **LAPLANTE** piston compressors are intended for the compression of ambient air. The air may not contain any aggressive or combustible mixtures.

The pressure chambers of the compressor are oil-lubricated. Therefore, the compressed air produced may only be used as breathing air or come into contact with food if it has been treated beforehand.



**As standard this LAPLANTE piston compressor is not of an explosion-protected design and it may not be operated in areas subject to explosion hazards!**



## Symbols used

We have used the following symbols in this text to mark particularly important points:



The general warning sign indicates information concerning possible danger to operator and machine.

The lightning symbol indicates work which must exclusively be performed by skilled electricians.

The pointing hand indicates particularly important statements.

The spanner indicates maintenance work.



**Danger** is used to indicate the presence of a hazard, which will cause severe personal injury, death or substantial equipment and property damage if the warning is ignored.



**Warning** is used to indicate the presence of a hazard that can cause severe personal injury, death or substantial equipment and property damage if the warning is ignored.



**Caution** is used to indicate the presence of a hazard that will or can cause personal injury or equipment and property damage if the warning is ignored.



**Notice** is used to notify people of installation, operation, or maintenance of information that is important but not hazard related.



## Symbols on the compressor

**Warning:**

Hot surfaces: Do not touch!

**Warning:**

The unit is operated by remote control, and might start without warning.

**Note:**

Instructions for the operating personnel must be read.

**Prohibited:**

Never open the valve before the air hose (connection to the compressed air network) is connected.

**Forbidden**

TO remove protective covering and safety devices

**Danger:**


Hot or noxious gases outlet: unbreathable

**Danger:**

High voltage disconnect power source before servicing



**Danger:**  
**Spray injury!**



## Safety Guide

### Compressor Safety Precautions



An air compressor is a dynamic piece of machinery needing the same common sense safety precautions that should be observed with any operating machinery. Careless operation or maintenance is hazardous to personnel.



In addition to the obvious safety rules that should be followed with machinery, we recommend the following additional safety precautions.

1. Read and understand all instructions completely before operating this compressor.
2. Disengage power mains and disconnect power lines to the machine, if used, prior to attempting to work or perform maintenance on this unit.
3. Open tank discharge valve and relieve all pressure from tank and compressor lines.  
Do not attempt to remove any pressurized system parts without first relieving the pressure within the unit.
4. Do not attempt to service any part while the machine is in operation.
5. Do not operate the compressor at pressures in excess of its indicated rating on the compressor nameplate.
6. Do not operate the compressor at speeds in excess of its indicated rating on the compressor nameplate.
7. Do not remove guards, shields, or screens while the compressor is operating. If removed for maintenance replace before resuming operation.
8. Observe the delivery pressure gauge daily to be sure the automatic control system is operating within proper limits.
9. Periodically check all safety and relief devices for proper operation.
10. Do not play with compressed air. Pressurized air can cause serious injury or death to personnel.
11. Be sure that no tools, rags, or loose parts are left on the compressor or drive parts.

12. Do not use flammable solvents for cleaning parts.
13. Exercise cleanliness during maintenance and when making repairs.  
Keep dirt away from parts and exposed openings by covering with a clean cloth or Kraft paper.
14. Install pressure relief valves in any isolatable piping in the plant system.
15. Do not operate the compressor in areas where there is the possibility of ingesting flammable or toxic gases.
16. Check pipe for any signs of wear or deterioration before each use and make certain that all connections are secure.
17. Observe the prescribed maintenance intervals.
18. Only use genuine **LAPLANTE** parts.
19. Only use **LAPLANTE** compressor oils and operating material recommended by **LAPLANTE**.
20. Strictly observe the effluent disposal laws of your local authority when disposing of condensate!



Make sure to investigate the code requirements to ensure compliance prior to operating the compressor.



The owner, lessor, or operator of this compressor is hereby notified and forewarned that any failure to observe these safety precautions may result in injury, death and/or property damage.

| Contents                             | Page     |
|--------------------------------------|----------|
| <b>SECTION I</b>                     | <b>1</b> |
| INTRODUCTION                         | 1        |
| UNPACKING AND HANDLING               | 2        |
| APPROPRIATE USE                      | 4        |
| SYMBOLS USED                         | 5        |
| SYMBOLS USED                         | 5        |
| SYMBOLS ON THE COMPRESSOR            | 6        |
| SAFETY GUIDE                         | 8        |
| <b>SECTION II</b>                    | <b>1</b> |
| INSTALLATION INSTRUCTION             | 1        |
| TECHNICAL DATA                       | 1        |
| EXPLODE DRAWING                      | 2        |
| BILL OF MATERIAL LIST                | 3        |
| INSPECTION                           | 5        |
| HEAD UNLOADER                        | 7        |
| CENTRIFUGAL UNLOADER                 | 11       |
| OPERATION                            | 14       |
| <b>SECTION III</b>                   | <b>1</b> |
| PARTS KITS                           | 1        |
| OVERHAUL KIT                         | 1        |
| RING SET                             | 1        |
| VALVE SET                            | 1        |
| GASKET SET                           | 1        |
| BOLT TORQUE CHART                    | 2        |
| DISASSEMBLE PUMP                     | 3        |
| ASSEMBLE PUMP                        | 5        |
| TROUBLESHOOTING                      | 7        |
| MAINTENANCE                          | 7        |
| GENERAL                              | 7        |
| SAFETY INFORMATION                   | 8        |
| CHECK OIL LEVEL                      | 8        |
| CHECK AND CLEAN COMPRESSOR VALVES    | 10       |
| CHECK THE SAFETY VALVE               | 11       |
| CHANGE OIL                           | 14       |
| CHECK AND CHANGE AIR FILTER          | 14       |
| MAINTENANCE SCHEDULE                 | 15       |
| LIST OF MAINTENANCE AND SERVICE WORK | 16       |

## Introduction

These operating instructions form part of the machine and must be made available to the compressor operating personnel at all times. In order to receive maximum performance and long life from your compressor, the following instructions should carefully read and all points regarding installation and operation of the unit should be noted and observed. Careful reading of this manual, prior to connecting anything to the motor or compressor, will pay dividends in long term trouble-free operation.



## Unpacking and Handling



Occasionally damage will occur during shipping. Be sure to carefully inspect the unit before unpacking and after unpacking **BEFORE** you sign the receiver. If any has occurred, document it with the trucking firm immediately. Contact your LAPLANTE representative for assistance.

To move your compressor to its installation site we recommend that you leave the unit on its shipping skid as long as possible. The forks should be extended the width of the compressor and padding should be placed between the compressor and the fork truck boom.

If it is necessary to lift the compressor with a crane, we recommend the use of spreader bar and chains. The spreader bar should be greater than the width of the compressor and padding placed on the edges to prevent chain damage.



### **DO NOT UTILIZE THE PUMP OR DRIVE AS A LIFT POINT**

#### **Procedure for Handling Damaged Shipments**

1. The customer, at the receiving point, **MUST** inspect each shipment for damage.
2. If the shipment is damaged, the customer should so note it on the freight bill.
3. The customer should request an inspector from the freight company to inspect the equipment immediately. It is best to send a confirming letter with the following information:
  - a. Freight bill number.
  - b. Date delivered - shipper's name & address.
  - c. Description of item(s) damaged.
  - d. Description of damage (a Polaroid picture if possible).
  - e. A copy of your invoice for the equipment.
4. After inspection, (before the inspector leaves):
  - a. Get a copy of the inspection report.
  - b. Request the unit be shipped back "free astray".
  - c. Request a credit for the original freight bill.
5. Call the factory and:
  - a. Get a Return Material Authorization (RMA number).
  - b. Give a purchase order for repair. The purchase order should refer to the item and trucker claim.



6. We will accept the shipment back, repair (under normal conditions) and return it within (7) seven working days.
7. We will invoice the customer for the repair, which will then become part of your claim. The Invoice must be presented to the trucking claim department along with their claim form.
8. We suggest if the trucker does not pay within 30 days that you call and / or write the ICC making a formal complaint of poor service. Also advise **LAPLANTE** in writing for follow-up.  
If damage can be repaired at the receiving point, follow Procedure 1, steps 1 through 4a. Repair the unit and make out a detailed invoice to the trucker showing labor hours, labor rate, materials used, and cost of materials.


### Storage

In some cases it may necessary to store the compressor for extended periods of several months before placing the unit in operation. When this is required do the following:

- Cover and seal all machine openings to prevent the entrance of water and dirt.
- Cover all openings in open drip proof motors to prevent the entrance of rodents.
- If the storage conditions are below freezing, drain off the tank, traps, and attendant piping.
- We do not recommend outside storage.
- Cover with a waterproof tarpaulin that can easily be removed for in storage maintenance.
- While in storage, every two to three months rotate the compressor and motor by hand to prevent flat spots on the bearings that will lead to premature failure.
- At the end of the storage period, follow the uncrating and start-up procedures. If the unit has been stored for more than eighteen months you should contact **LAPLANTE** before restarting the compressor.



TRADE SECRET –CONFIDENTIAL AND PROPRIETARY  
EXCLUSIVELY OWNED BY LAPLANTE COMPRESSOR, LTD.,  
ANY COPYING, USE OR DISCLOSURE WITHOUT THE WRITTEN  
PERMISSION OF LAPLANTE COMPRESSOR, LTD. IS STRICTLY  
PROHIBITED. THIS MATERIAL IS PROTECTED UNDER  
TRADE SECRET AND UNFAIR COMPETITION LAWS. THE  
EXPRESSION OF THE INFORMATION IS PROTECTED UNDER  
FEDERAL COPYRIGHT LAWS. VIOLATIONS MAY RESULT IN  
CIVIL AND CRIMINAL FINES AND PENALTIES.



Specification:

- Pump:
- Type: LPSS7550
  - Cylinders: 2
  - Bore : 2.95"/75mm
  - Stroke: 1.97"/50mm
  - RPM: 1026
  - Pump Flywheel: 12"/305mm/1A

- Motor:
- Power: 3HP/2.24Kw
  - Voltage: 230V
  - Phase: 1PH
  - Frequency: 60Hz
  - Amps: 15 A
  - RPM: 3450RPM
  - Motor Pulley:

- Tank:
- 60Gal/228Ltr
  - Max. Pressure: 175Psi

- Pressure Switch:
- Pressure Range: 125~155Psi

Rating CFM @ 125Psi: 11.71  
                  @ 145Psi: 11.51  
                  @ 155Psi: 11.32

Rating ACFM @ 125Psi: 11.36  
                  @ 145Psi: 11.16  
                  @ 155Psi: 10.98

- Standard Package:
- Single : 1 Pcs,Weight: XXXLB/XXXKg
  - Crate : xxx Pcs,Weight: xxxLB/xxxxKg
  - 20' Container : xxx Pcs
  - 40' Container : xxx Pcs



Address:7502 Mesa Road Houston, TX77028  
Telephone: (713) 635-6291  
E-mail: sales@Lapante.com  
Web Site: www.Laplantecompressor.com

---

# ***Operating instructions***

## **Industrial piston air compressors**

**Model: LPSS7550**

7502 Mesa Road Houston, TX77028

Telephone: (713) 635-6331

E-mail: [service@lapante.com](mailto:service@lapante.com)

Web Site: [www.lapantecompressor.com](http://www.lapantecompressor.com)



Issue: 06/2010

| Contents                                   | Page |
|--|------|
| <b>SECTION I</b> .....                     | 1    |
| INTRODUCTION .....                         | 1    |
| UNPACKING AND HANDLING .....               | 2    |
| APPROPRIATE USE .....                      | 4    |
| SYMBOLS USED .....                         | 5    |
| SYMBOLS USED .....                         | 5    |
| SYMBOLS ON THE COMPRESSOR .....            | 6    |
| SAFETY GUIDE .....                         | 8    |
| <b>SECTION II</b> .....                    | 1    |
| INSTALLATION INSTRUCTION .....             | 1    |
| TECHNICAL DATA .....                       | 1    |
| EXPLODE DRAWING.....                       | 2    |
| BILL OF MATERIAL LIST.....                 | 3    |
| INSPECTION .....                           | 4    |
| OPERATION .....                            | 6    |
| <b>SECTION III</b> .....                   | 1    |
| PARTS KITS.....                            | 1    |
| OVERHAUL KIT .....                         | 1    |
| RING SET.....                              | 1    |
| VALVE SET .....                            | 1    |
| GASKET SET .....                           | 1    |
| BOLT TORQUE CHART.....                     | 2    |
| DISASSEMBLE PUMP .....                     | 3    |
| ASSEMBLE PUMP.....                         | 5    |
| TROUBLESHOOTING .....                      | 7    |
| MAINTENANCE .....                          | 7    |
| GENERAL.....                               | 7    |
| SAFETY INFORMATION .....                   | 8    |
| CHECK OIL LEVEL .....                      | 8    |
| CHECK AND CLEAN COMPRESSOR VALVES.....     | 10   |
| CHECK THE SAFETY VALVE .....               | 11   |
| CHANGE OIL .....                           | 14   |
| CHECK AND CHANGE AIR FILTER.....           | 14   |
| MAINTENANCE SCHEDULE .....                 | 15   |
| LIST OF MAINTENANCE AND SERVICE WORK ..... | 16   |

## Introduction

These operating instructions form part of the machine and must be made available to the compressor operating personnel at all times. In order to receive maximum performance and long life from your compressor, the following instructions should carefully read and all points regarding installation and operation of the unit should be noted and observed. Careful reading of this manual, prior to connecting anything to the motor or compressor, will pay dividends in long term trouble-free operation.



## Unpacking and Handling



Occasionally damage will occur during shipping. Be sure to carefully inspect the unit before unpacking and after unpacking **BEFORE** you sign the receiver. If any has occurred, document it with the trucking firm immediately. Contact your LAPLANTE representative for assistance.

To move your compressor to its installation site we recommend that you leave the unit on its shipping skid as long as possible. The forks should be extended the width of the compressor and padding should be placed between the compressor and the fork truck boom.

If it is necessary to lift the compressor with a crane, we recommend the use of spreader bar and chains. The spreader bar should be greater than the width of the compressor and padding placed on the edges to prevent chain damage.



### **DO NOT UTILIZE THE PUMP OR DRIVE AS A LIFT POINT**

#### **Procedure for Handling Damaged Shipments**

1. The customer, at the receiving point, **MUST** inspect each shipment for damage.
2. If the shipment is damaged, the customer should so note it on the freight bill.
3. The customer should request an inspector from the freight company to inspect the equipment immediately. It is best to send a confirming letter with the following information:
  - a. Freight bill number.
  - b. Date delivered - shipper's name & address.
  - c. Description of item(s) damaged.
  - d. Description of damage (a Polaroid picture if possible).
  - e. A copy of your invoice for the equipment.
4. After inspection, (before the inspector leaves):
  - a. Get a copy of the inspection report.
  - b. Request the unit be shipped back "free astray".
  - c. Request a credit for the original freight bill.
5. Call the factory and:
  - a. Get a Return Material Authorization (RMA number).
  - b. Give a purchase order for repair. The purchase order should refer to the item and trucker claim.



6. We will accept the shipment back, repair (under normal conditions) and return it within (7) seven working days.
7. We will invoice the customer for the repair, which will then become part of your claim. The Invoice must be presented to the trucking claim department along with their claim form.
8. We suggest if the trucker does not pay within 30 days that you call and / or write the ICC making a formal complaint of poor service. Also advise **LAPLANTE** in writing for follow-up.  
If damage can be repaired at the receiving point, follow Procedure 1, steps 1 through 4a. Repair the unit and make out a detailed invoice to the trucker showing labor hours, labor rate, materials used, and cost of materials.

### Storage

In some cases it may necessary to store the compressor for extended periods of several months before placing the unit in operation. When this is required do the following:

- Cover and seal all machine openings to prevent the entrance of water and dirt.
- Cover all openings in open drip proof motors to prevent the entrance of rodents.
- If the storage conditions are below freezing, drain off the tank, traps, and attendant piping.
- We do not recommend outside storage.
- Cover with a waterproof tarpaulin that can easily be removed for in storage maintenance.
- While in storage, every two to three months rotate the compressor and motor by hand to prevent flat spots on the bearings that will lead to premature failure.
- At the end of the storage period, follow the uncrating and start-up procedures. If the unit has been stored for more than eighteen months you should contact **LAPLANTE** before restarting the compressor.

## Appropriate use

As standard, **LAPLANTE** piston compressors are intended for the compression of ambient air. The air may not contain any aggressive or combustible mixtures.

The pressure chambers of the compressor are oil-lubricated. Therefore, the compressed air produced may only be used as breathing air or come into contact with food if it has been treated beforehand.



**As standard this LAPLANTE piston compressor is not of an explosion-protected design and it may not be operated in areas subject to explosion hazards!**



## Symbols used

We have used the following symbols in this text to mark particularly important points:



The general warning sign indicates information concerning possible danger to operator and machine.

The lightning symbol indicates work which must exclusively be performed by skilled electricians.

The pointing hand indicates particularly important statements.

The spanner indicates maintenance work.



**Danger** is used to indicate the presence of a hazard, which will cause severe personal injury, death or substantial equipment and property damage if the warning is ignored.



**Warning** is used to indicate the presence of a hazard that can cause severe personal injury, death or substantial equipment and property damage if the warning is ignored.



**Caution** is used to indicate the presence of a hazard that will or can cause personal injury or equipment and property damage if the warning is ignored.



**Notice** is used to notify people of installation, operation, or maintenance of information that is important but not hazard related.




## Symbols on the compressor

**Warning:**

Hot surfaces: Do not touch!

**Warning:**

The unit is operated by remote control, and might start without warning.

**Note:**

Instructions for the operating personnel must be read.

**Prohibited:**

Never open the valve before the air hose (connection to the compressed air network) is connected.

**Forbidden**

TO remove protective covering and safety devices

**Danger:**


Hot or noxious gases outlet: unbreathable

**Danger:**

High voltage disconnect power source before servicing



**Danger:**  
**Spray injury!**



12. Do not use flammable solvents for cleaning parts.
13. Exercise cleanliness during maintenance and when making repairs.  
Keep dirt away from parts and exposed openings by covering with a clean cloth or Kraft paper.
14. Install pressure relief valves in any isolatable piping in the plant system.
15. Do not operate the compressor in areas where there is the possibility of ingesting flammable or toxic gases.
16. Check pipe for any signs of wear or deterioration before each use and make certain that all connections are secure.
17. Observe the prescribed maintenance intervals.
18. Only use genuine **LAPLANTE** parts.
19. Only use **LAPLANTE** compressor oils and operating material recommended by **LAPLANTE**.
20. Strictly observe the effluent disposal laws of your local authority when disposing of condensate!



Make sure to investigate the code requirements to ensure compliance prior to operating the compressor.



The owner, lessor, or operator of this compressor is hereby notified and forewarned that any failure to observe these safety precautions may result in injury, death and/or property damage.

## Safety Guide

### Compressor Safety Precautions






An air compressor is a dynamic piece of machinery needing the same common sense safety precautions that should be observed with any operating machinery. Careless operation or maintenance is hazardous to personnel.



In addition to the obvious safety rules that should be followed with machinery, we recommend the following additional safety precautions.

1. Read and understand all instructions completely before operating this compressor.
2. Disengage power mains and disconnect power lines to the machine, if used, prior to attempting to work or perform maintenance on this unit.
3. Open tank discharge valve and relieve all pressure from tank and compressor lines.  
Do not attempt to remove any pressurized system parts without first relieving the pressure within the unit.
4. Do not attempt to service any part while the machine is in operation.
5. Do not operate the compressor at pressures in excess of its indicated rating on the compressor nameplate.
6. Do not operate the compressor at speeds in excess of its indicated rating on the compressor nameplate.
7. Do not remove guards, shields, or screens while the compressor is operating. If removed for maintenance replace before resuming operation.
8. Observe the delivery pressure gauge daily to be sure the automatic control system is operating within proper limits.
9. Periodically check all safety and relief devices for proper operation.
10. Do not play with compressed air. Pressurized air can cause serious injury or death to personnel.
11. Be sure that no tools, rags, or loose parts are left on the compressor or drive parts.

TRADE SECRET –CONFIDENTIAL AND PROPRIETARY  
EXCLUSIVELY OWNED BY LAPLANTE COMPRESSOR, LTD.,  
ANY COPYING, USE OR DISCLOSURE WITHOUT THE WRITTEN  
PERMISSION OF LAPLANTE COMPRESSOR, LTD. IS STRICTLY  
PROHIBITED. THIS MATERIAL IS PROTECTED UNDER  
TRADE SECRET AND UNFAIR COMPETITION LAWS. THE  
EXPRESSION OF THE INFORMATION IS PROTECTED UNDER  
FEDERAL COPYRIGHT LAWS. VIOLATIONS MAY RESULT IN  
CIVIL AND CRIMINAL FINES AND PENALTIES.



## Specification:

- Power Range: 1.5~4.5HP/1~3.5Kw
- Maximum Pressure: 155Psi/11Bar
- Cylinders: 2
- Bore : 2.95"/75mm
- Stroke: 1.97"/50mm
- RPM: 400~1400
- Flywheel Dia./Groove: 12"/305mm/1A

## Features:

- Cast Iron Crankcase
- Cast Iron Cylinder
- Cast Iron Cylinder Head
- Ductile Iron Crankshaft
- Aluminun Conn. Rod
- Bronze Bushings Wrist Pin
- Babbitt Bearings Crankshaft
- Ball Main Bearings
- Steel Breather and Brass Sight Glass
- Power Coated Steel Filter Silencer
- Filled with DAB150 Lubricant
- Synthetic Lubricant as Optional

## Standard Package:

- Single : 1 Pcs,Weight:52LB/23Kg
- Crate : 25 Pcs,Weight:1367LB/605Kg
- 20' Container : 750 Pcs
- 40' Container : 950 Pcs




Address:7502 Mesa Road Houston, TX77028  
Telephone: (713) 635-6291  
E-mail: sales@Lapante.com  
Web Site: www.Lapantecompressor.com


TITLE

# LPSS7550 Specifications

LPS7550 Performance (Delivery)




LPS7550 Performance (Power)





Explode drawing



## Bill of material list

| LPS7550 Parts List |        |   |     |
|--------------------|--------|---|-----|
| Item               | LAP#   | Description                             | QTY |
| A                  | 010045 | Overhual Kit:Include 1 of B,C,D         |     |
| B                  | 010046 | Ring Set:Include 1 of Item 44,45,46     |     |
| C                  | 010047 | Valve Set:Include 1 of Item 25          |     |
| D                  | 010048 | Gasket Set:Include 1 of Item 7,17,21,32 |     |
| 1                  | 110222 | Hex Head Cap Screw - M8x35              | 1   |
| 2                  | 130058 | Lockwasher - M8                         | 11  |
| 3                  | 140044 | Flate Washer Flywheel                   | 1   |
| 4                  | 713157 | Flywheel 12" 1A                         | 1   |
| 5                  | 110117 | Hex Head Cap Screw - M8x20              | 4   |
| 6                  | 701137 | Cap Drive End                           | 1   |
| 7                  | 070368 | Gasket-Drive End Cap                    | 1   |
| 8                  | 060185 | Oil Seal                                | 1   |
| 9                  | 050772 | Ball Bearing - 206                      | 1   |
| 10                 | 080035 | Key 5 x 5                               | 1   |
| 11                 | 709220 | Crankshaft                              | 1   |
| 12                 | 708052 | Crankcase                               | 1   |
| 13                 | 731002 | Oil Level Sight Glass 1/2"NPT           | 1   |
| 14                 | 140037 | Plug Drain 3/8" NPT                     | 1   |
| 15                 | 050155 | Ball Bearing - 205                      | 1   |
| 16                 | 703007 | Breather                                | 1   |
| 17                 | 070370 | Gasket Rear Cap                         | 1   |
| 18                 | 701139 | End Cap-Rear                            | 1   |
| 19                 | 130082 | Lockwasher - M6                         | 6   |
| 20                 | 110223 | Hex Head Cap Screw - M6x16              | 5   |
| 21                 | 070372 | Gasket Cylinder/Crankcase               | 1   |
| 22                 | 711166 | Cylinder                                | 1   |
| 23                 | 110147 | Hex Head Cap Screw M8x25                | 6   |
| 24                 | 070374 | Gasket - Cylinder/Valve deck            | 1   |
| 25                 | 727257 | Valve Deck Complete                     | 1   |
| 26                 | 120053 | Hex Nut M3                              | 4   |
| 27                 | 130061 | Lockwasher M3                           | 4   |
| 28                 | 110109 | Socket Head Cap Screw M3X12             | 4   |
| 29                 | 727258 | Valve Plate                             | 1   |
| 30                 | 727259 | Valve Discharge 0,25mm                  | 2   |
| 31                 | 727260 | Valve Stop Plate                        | 2   |
| 32                 | 070283 | Gasket - Cylinder Head                  | 1   |
| 33                 | 110120 | Socket Head Cap Screw - M8x35(8.8)      | 4   |
| 34                 | 110225 | Socket Head Cap Screw - M8x60(8.8)      | 4   |
| 35                 | 710017 | Cylinder Head Ass                       | 1   |
| 36                 | 110112 | Philips Head Screw M4X5                 | 4   |
| 37                 | 130055 | Lockwasher M4                           | 7   |
| 38                 | 727262 | Inlet Valve 0.2mm                       | 2   |
| 39                 | 710019 | Cylinder Head Iron                      | 1   |
| 40                 | 712200 | Screen                                  | 2   |
| 41                 | 712201 | Air Center Muffler                      | 1   |
| 42                 | 110113 | Philips Head Screw M4X8                 | 3   |
| 43                 | 712202 | Inlet Cover Alum                        | 1   |
| 44                 | 710038 | Compression Ring Top                    | 2   |
| 45                 | 719035 | Compression Ring Middle                 | 2   |
| 46                 | 719036 | Oil Control Ring                        | 2   |
| 47                 | 720017 | Poston                                  | 2   |
| 48                 | 729012 | Wrist Pin                               | 2   |
| 49                 | 200108 | Snap Ring 1/2" Internal                 | 4   |
| 50                 | 750048 | Connecting Rod                          | 2   |
| 51                 | 100106 | Connecting Rod Alignment Dowel          | 4   |
| 52                 | 050125 | Connecting Rpd Insert Bearing           | 4   |
| 53                 | 110151 | Socket Head Cap Screw M8X35 (Class10.9) | 4   |

## Installation Instruction

### 1. Inspection

Check for possible damage in transit and see that the pulley turns freely by hand Report any damage to delivering carrier at once.

### 2. Location

Select a clean, dry and light location. In cold climates the compressor should be installed in a heated building Insulate cold water or other low temperature pipes that pass overhead to avoid the possible collection and dripping of condensate onto the compressor and motor which could cause rusting and or motor shorting Do not install the compressor in a boiler room, paint spray room or area where sandblasting is carried on. If air in the area where the compressor is to be installed is acid-laden, or dust laden the compressor intake should be piped to the outside This intake pipe should be increased one pipe size for every twenty (20) feet of run and the intake filters should be installed at the end of the pipes with a hood to protect them from the elements.

If the compressor has to be located where the motor will be exposed to appreciable quantities of water, oil dirt, acid or alkaline fumes the motor must be of special construction to avoid rapid deterioration.

Bolt the unit securely and evenly to a level base. Unless base is exactly level, shims will probably be required. Any space between base and foot should be shimmed rather than drawing foot down thus placing strain on unit. When the unit is properly shimmed vibration will be nominal.

Allow sufficient space around compressor so that it is accessible from all sides for maintenance. Mount unit with pulley side toward the wall. but at least six (6) inches from it.

### 3. Starting

A. If compressors are shipped without oil in the crankcase. Before starting. fill crankcase to the high level mark on the sight glass with LaPlante compressor oil meeting the following specifications.

| AMBIENT OR ROOM TEMP. °F | VISCOSITY AT 100° F S.S.U. | FLASH POINT °F (Min.) | POUR POINT °F (Min.) | CARBON RESIDUE %o (Max.) | PREFERRED BASE |
|--------------------------|----------------------------|-----------------------|----------------------|--------------------------|----------------|
| 55 to 120                | 490 to 600                 | 430                   | • 20                 | 15                       | Naphthenic     |
| 32 to 55                 | 290 to 350                 | 390                   | * 5                  | 10                       | Naphthenic     |
| 0 to 32                  | 160 to 230                 | 350                   | -10                  | .05                      | Naphthenic     |
| Above 120 or below 0     | CONSULT FACTORY            |                       |                      |                          |                |





For operation in damp or humid locations, addition of rust inhibitor is recommended.

**B.** Turn compressor over a few revolutions by hand to make sure that everything is free and in running condition.

**C.** Check tension of the belts (See Paragraph 6).

**D.** Remove tools, rags and any other objects from the vicinity of the compressor.

**E.** Never put hands on the belts of idle units, unless main power is secured.

**F.** Note direction of arrow on flywheel and be sure direction of rotation is correct when machine is started. Correct direction is counter-clockwise when standing facing the flywheel. Air should be drawn through inter-cooler onto the cylinders for maximum cooling.



## Operation

Every compressor undergoes a trial run in the factory and is carefully tested and set. However, damage occurring afterwards, e.g. during transport, cannot be excluded. Therefore, the compressor should always be subjected to a trial run during commissioning and carefully monitored.



**Before start pump must be do the following job first!!!**

**Check power supply and ;  
Check oil level; top up if necessary;  
Check fastener and piping connection。**

**For 3-phase power:**

**Ensure no problem; start-up pump to check rolling direction, counter-clockwise is right, if not, please change 2 of 3-phase power wiring.**

**If all items are ok, start the pump in operating.**

## Parts Kits

**About parts kits of pump include 4 sets:**

1. Overhaul Kit: Includes 1 each of filter element and ring set, valve set, gasket set.
2. Ring Set: Includes 1 set of piston rings.
3. Valve Set: Includes 1 set of inlet valve and outlet valve.
4. Gasket Set: Includes 1 each of gasket.



**For each pumps you can find the relevant parts kits number and describe in the explode drawings and bom list section.**

### Safety information



**Please observe the following instructions when performing any maintenance, cleaning, repair work; when relocating the compressor plant; prior to installing and dismounting component parts, receivers, fittings and screw connections.**

- **Always isolate the compressor at the main switch prior to performing any maintenance work.**

**Secure the main switch against accidental switching on! Remove the electrical fuses in order to avoid accidents!**

- **Depressurize the compressor!**

**Disconnect from the compressed air network by closing the ball valve on the compressed air outlet.**

**Perform maintenance or servicing work.**

**Only allow skilled and qualified welders to perform welding work on compressed air receivers!**

**After welding work on compressed air receivers, new constructional and hydrostatic pressure tests are to be carried out.**

- **Prior to switching on again, check whether anyone else is working on the compressor!**

**For your own safety, never omit a safety step!**

**Otherwise you will risk injury from restarting, electric shock or parts which may fly off!**

**Bolt torque chart**

| Bolts Size | Grade | Torque(Ft.-Lb.) | Position               |
|------------|-------|-----------------|------------------------|
| M6X20      | 8.8   | 5.5             | End Cover Bolt         |
| M6X25      | 8.8   | 5.5             | End Cover Bolt         |
| M6X35      | 8.8   | 5.5             | Head to Cylinder Bolt  |
| M8X20      | 8.8   | 13.5            | LP & HP Hold Down Bolt |
|            |       |                 | End Cover Bolt         |
| M8X25      | 8.8   | 13.5            | Cylinder to Base Bolt  |
| M8X35      | 10.9  | 13.5            | Connecting Rod Bolt    |
| M8X60      | 8.8   | 13.5            | Head to Cylinder Bolt  |
| M8X65      | 8.8   | 13.5            | Head to Cylinder Bolt  |
| M10X25     | 8.8   | 26              | Cylinder to Base Bolt  |
| M10X45     | 10.9  | 26              | Connecting Rod Bolt    |
| M12X35     | 8.8   | 45              | Cylinder to Base Bolt  |
| M12X70     | 8.8   | 45              | Head to Cylinder Bolt  |
| M12X110    | 8.8   | 45              | Cylinder to Base Bolt  |
| M16X80     | 8.8   | 110             | Flywheel Bolt          |

**Disassembling Pump**

Before dismantling a pump for overhauling it is advisable to obtain a set of valve parts, piston rings, and gaskets in addition to other required parts.

- A. Loosen motor, slide toward pump and remove belts. Drain oil from crankcase and if desired, remove complete pump from plat form.
- B. Remove flywheel bolt and remove pulley using a wedge or wheel puller if required. Remove key File edges of key way smooth to remove sharp edges which could cut oil seal during removal.
- C. Remove air inlet filter from head.
- D. Remove cylinder head from cylinder by removing cap screws.
- E. Before removing cylinder mark top of pistons nearest flywheel, so that they can be reinstalled in same position. Remove cylinder by removing bolts Cylinder can be removed easily by twisting slightly back and forth while pulling upward. Care should be taken that connecting rod and piston does not become damaged from striking metal when cylinder is removed The condition of cylinder, pistons, rings and bearing fits can then be checked.
- F. Remove end cover and slide crankshaft with connecting rods, pistons, etc. out

of base being careful not to damage the oil feeder ring. Place pulley end of crankshaft in a vice using a soft jaws to prevent damage.

- G. To remove pistons. Remove roll pins, by driving them into the wrist pins, and push out wrist pins. Remove roll pins from wrist pins.
- H. When removing connecting rods see that rods and caps are kept in matched sets, noting the position with reference to the crankshaft of the identification marks on one side of each so that the connecting rod can be replaced in the same position it originally occupied.
- I. Drive oil seal out of base (only if replacement is necessary) with evenly spaced blows from inside.
- J. To dismantle head, remove low pressure hold-down covers and high pressure hold-down covers by removing cap screws. Lift out low pressure cages and high pressure cages. Low pressure valves and high pressure valves can be lifted out as well as the low pressure seat gasket (15. fig. 4) and high pressure seat gasket.
- K. To dismantle valves, place valve in a soft jaw vise and remove center screw. Valves are now free to take apart. Clean all parts thoroughly. Valve plates and seats- (must be smooth and flat and can sometimes be resurfaced by rubbing on fine emery cloth held on a smooth surface. Badly worn parts including springs, which lose tension after considerable use should be replaced.

### Fitting and Reassembling



Clean all parts thoroughly before assembling.

#### A. Crankshaft — Base

Be sure base is cleaned to remove all metal chips and dirt. Insert crankshaft and oil feeder ring only into base assemble end cover and tighten end cover bolts evenly. End cover gaskets or shims are furnished in three thicknesses and the proper combination must be selected so that crankshaft can be "spun" in the bearings without "end play". Also see that oil feeder ring turns freely within the guide lugs in the base. Then remove crankshaft.

#### B. Piston — Cylinder

Check fit before assembling pistons to connecting rods. Pistons without rings should slide through the cylinder of their own weight and holding the skirt of the piston with the two thumbs there should be no appreciable side motion at any point of piston travel. Scored cylinders or pistons should be replaced. C. Wrist Pins should be "tap" fit by hammer. See that roll pin holes are in line.

#### D. Wrist Pin — Needle Bearing

Fit so that piston can be "rocked" with three fingers — the thumb on one side and index and middle fingers on the other. The piston should not rock of its own weight. Drive roll pin into wrist pin when piston and wrist pin holes are in line and piston is assembled to connecting rod. If replacement of a needle bearing ever becomes necessary, be sure to press in the new bearing so that the small hole through casting lines up with oil hole in rod. Wrist pin should also be replaced.

- E. Connecting Rod — Crankshaft Tap cap, when insert bearings are assembled to rod and cap to make sure bearing is making contact and tighten rod bolts with lock washers in place to prevent loosening (torque — 25 foot pounds). The combined piston and connecting rod should turn slowly on the crankshaft of their own weight if bearing adjustment incorrect. It will be noted that ends of the inserts extend slightly above the parting line of the rod and cap and under no circumstance should these ends of the inserts be filed.
- F. Reinstall crankshaft with pistons and connecting rods attached being careful not to damage oil feeder ring when fitting within base lugs and being sure there are no burrs or dirt on the pulley end of the crankshaft that might cut the oil seal.
- G. If oil seal is to be replaced slide over the crankshaft and press into place in the base, the lip or seal side toward the crankcase. Do not hammer directly on the seal.
- H. Replace valve parts in sequence indicated in explode drawing being careful not to force any parts together when tightening this center screw and locknut (Torque — 28 foot — pounds). After assembly depress valve plate to insure that the valve works freely.
- I. Install key and pulley after cylinder head, intercooler and after-cooler are connected.
- J. Turn pulley over by hand several times to insure that no interference of any kind exists.
- K. "Running in" for a few hours without the head assembly is recommended if a pump has been completely overhauled — especially if new pistons and/or cylinders have been installed.

### Valves

Valves are generally considered to be maintenance items and require care by the user. They are the most important part of the compressor and the importance of proper care and maintenance cannot be over-emphasized.

All valves should be removed from the cylinder head at the end of the first two or three months of operation and examined for cleanliness and carbon formation. Clean with safety solvent and blow off with compressed air. Depending on what is found at this inspection, the next inspection should not be more than 4 to 6 months later. These 2 inspections will guide you in scheduling periodic cleaning times which will pay off many times over in providing trouble free service and reduced down time.

## Troubleshooting

### 1. Slow Pumping Or Insufficient Pressure Can Be Caused By

- A Clogged inlet filter — (Disassemble and clean thoroughly.)
- B Leaks in air lines, valves, fittings, etc. (Locate using soapy water if necessary: replace or tighten threaded parts.)
- C Compressor too small for equipment being operated — (Check air requirements and add to compressor capacity — consult dealer.)
- D Leaking head valves - (Remove hold-down covers and remove valves for examination. Repair or replace faulty valves.) Valves can be removed from head by tapping valve screw with hammer handle or piece of wood, to loosen valve from head, before lifting valve.  
Clean all parts thoroughly. Valves and seats must be flat and smooth and sometimes can be



resurfaced by rubbing on fine emery cloth held on a smooth flat surface. Badly worn parts, including springs which lose tension after considerable use should be replaced. Reassemble valve parts in sequence indicated in explode drawing. Examine valve gaskets carefully and replace if doubtful of condition. Be careful that nothing falls into the cylinder that could get caught between top of piston and cylinder head. Before reassembling valve look into cylinder through valve opening while turning flywheel by hand.

## 2. Excessive Oil Consumption

"Oil Pumping" usually results from using the wrong type or an inferior grade of oil. Replacing worn or stuck piston rings will help correct this condition but contrary to popular belief, worn rings do not affect pumping efficiency appreciably.

Piston rings can be replaced by removing cylinder while the heads are off. Remove rings and clean grooves in piston.

The low pressure oil ring provided is of the latest design and is the same as furnished on the new automobile engines. It is of three-piece construction with two chrome-plated rails and an expander ring. Some new units may pump a slight amount of oil for a period of time but as the chrome-plated rails seat to the cylinder walls this will gradually diminish. Should excessive oil consumption continue, the cylinders should be checked for scoring and the oil ring checked for proper assembly. The two ends of the expander rings are colored with paint for identification and when properly assembled should be butted, not overlapped. The high pressure oil ring is of the one piece construction.

A coating of clean oil should be placed on the rings and the inside of the cylinders for ease of assembly and to minimize possibility of scoring cylinder. See Paragraph 16 for reassembly procedure.

## 3. Noisy Operation Can Be Caused By

- A. Loose parts — external — (Tighten loose bolts, particularly the flywheel pulley to the crankshaft.)
- B. Foreign matter such as carbon, metal chips, etc. on pistons striking head at top of stroke (Remove head and clean).
- C. Piston extending above cylinder at top of stroke and hitting head. (Remove cylinder and add base gasket, not upper cylinder gasket.)
- D. End play in crankshaft — (Remove end cover, take out one end cover gasket or shim and replace). Do not remove too many shims or binding may result, see Paragraph under fitting and reassembling.
- E. Loose valves — Hex head cap screws are not tight enough. (Tighten screws )



Screws should be tightened snugly but not too tight as hold-down cover corners could be broken. Screws should be tightened evenly keeping covers parallel with cylinder head. Screws have nylon insert in threads and are of self-locking construction. They will not loosen from vibration and can be removed and retightened several times without losing their holding ability.

F. Loose or worn parts — Internal, e.g. pistons, connecting rods, wrist pins, valves — (Pump should be overhauled — preferably in distributors service department or factory. Loose rod bolts can be tightened after removing crankshaft, but if bearings are worn or scored, new insert bearings must be installed.)

#### **4. Oil Leak**

At base or end cover gasket — (Disassemble at point of leak, shellac or perma-gasket on both sides and reassemble. Maintain correct oil level).

#### **5. Vibration**

Characteristic of all reciprocating machines can be held to a minimum by keeping the compressor securely fastened to a solid level foundation, maintaining proper belt alignment and keeping nuts and bolts tight.

#### **6. Overheating**

Compression of air generates heat, much of which is dissipated as air passes over the cylinder. Overheating can be caused by:

- A. Pump running backwards — (Reverse direction.) Proper rotation is counterclockwise facing flywheel.
- B. One or more head valves failing to seat properly — (Remove hold-down cover, valve cage, and valve. Clean, reseal or replace valves.)
- C. Blown cylinder head gasket — (Replace after cleaning all traces of old gasket from head and cylinder.)
- D. Restriction in head, intercooler or check valve if used. — (Remove and clean.)
- E. Lack of oil — (Check oil level, if necessary, remove side plate to see that oil feeder ring is free to turn.)
- F. Dirt in cylinder fins - (Blow out with air.)
- G. Poor ventilation and high room temperature  
(If compressor cannot be moved, check possibility of piping intake to cooler location.)

#### **7. Compressor Has No Or Insufficient Output**

- A. Suction filter soiled-( Clean suction filter)
- B. Suction and pressure valves worn or defective-( Replace valves)
- C. Vent (unloading) valve does not close-( Check whether the vent (unloading) valve closes when the compressor is running; overhaul or replace valve, if necessary)

#### **8. Safety Valve Of The First Stage Blows Off**

- A. Suction and pressure valves of the second stage defective or worn-( Replace valves)
- B. Seal between valve and cylinder head defective-( Replace seal)

#### **9. Oil Foam in The Crankcase**

- A. Last stage piston worn-( Operate compressor with final stage valve head removed. If oil collects at rim of cylinder, piston clearance ok. If oil flows continuously out of cylinder, replace piston and liner)
- B. Last stage outlet valve defective-( Replace)



## 10. Oil out of from the breather

Compressor piston jammed-(Replace pistons and cylinders)

## Maintenance



To obtain reliable and satisfactory service, this unit requires a consistent preventive maintenance program. Maintenance schedule pages are included in the back of this manual to aid in keeping the proper records.

### General

1. Check your compressor regularly!
2. Check entire system for air leakage around fittings, connections, and gaskets, using soap solution.
3. Remove dust or oil soiling.
4. Check fastener tightness by using torque wrench to the corresponding values within this guide.

### Safety information



Please observe the following instructions when performing any maintenance, cleaning, repair work; when relocating the compressor plant; prior to installing and dismounting component parts, receivers, fittings and screw connections.

- Always isolate the compressor at the main switch prior to performing any maintenance work.

Secure the main switch against accidental switching on! Remove the electrical fuses in order to avoid accidents!

- Depressurize the compressor!

Disconnect from the compressed air network by closing the ball valve on the compressed air outlet.

Perform maintenance or servicing work.

Only allow skilled and qualified welders to perform welding work on compressed air receivers!

After welding work on compressed air receivers, new constructional and hydrostatic pressure tests are to be carried out.

- Prior to switching on again, check whether anyone else is working on the compressor!

For your own safety, never omit a safety step!

Otherwise you will risk injury from restarting, electric shock or parts which may fly off!

**Check oil level**

Check oil level every week and top up, if necessary: fill the oil tank with oil until the sight glass is 1/4 to 3/4 full.



Oil sight glass

**Use the same brand oil****Check and clean compressor valves**

if compressor fails to pump air or seems slow in filling up tank, disconnect unit from power source and remove valves and clean thoroughly, using compressed air and a soft wire brush. After cleaning exceptional care must be taken that all parts are replaced in exactly the same position and all joints must be tight or the compressor will not function properly. When all valves are replaced and connections tight, close hand valve at tank outlet for final test. Valve gaskets should be replaced each time valves are removed from pump. Replace springs, discs and seats when worn or damage.



Valves must be reinstalled in original position. Incorrect valve replacement may result in overpressure of the cylinder head resulting in catastrophic failure, injury or death. Valve gaskets should be replaced each time valve are serviced.

**Checking the safety valve**

The safety valve must respond when the compressor pressure increases too high.

The inter stage pressure relief valve is provided to protect against inter stage over pressure and is factory set for maximum pressure of 75 PSIG. If the pressure relief valve pops open, it indicates trouble. Shut down the unit immediately and determine and correct the malfunction. Inspect the head valves. Serious damage can result if not corrected and can lead to complete destruction of the unit. Tampering with the inter stage pressure relief valve, or plugging the opening destroys the protection provided and voids all warranty.

The valve must be able to blow off the entire delivery quantity of the compressor. As it is rarely or never operated, it is of utmost importance for the safety of the compressor that the valve is regularly checked. Check the valve once a year or after 2000 operating hours.

This is the only maintenance work which has to be performed while the compressor is running. Make sure that all safety devices are correctly installed! Never perform this work with the safety device removed! Danger of injury or death!



**Do not readjust!!**

Test safety valve on compressor:

A ring is located at the free end of the safety valve. Pull the ring by hand. Never remove the lead seal at the head of the valve!

If you now pull the ring further, the safety valve should blow off increasingly more air.

If the valve blows off correctly, drop hand tight in its seating and complete the check.

- If the valve does not blow off although you have pull the ring up to the end of the stud, it is defective. Please have a new safety valve fitted by **LAPLANTE** Service.

Test the valve as described in section "Testing safety valve on compressor".

**Compressor Oil**

**General**

Compressors are factory filled with **LAPLANTE** hydrocarbon based recip lubricant. This is an ISO non-detergent industrial lubricant with rust and oxidation inhibitors specially formulated for reciprocating compressors. It is recommended this compressor be maintained using this oil for ambient temperature above 32 F degree.

LAPLANTE synthetic is a premium grade diester based synthetic lubricant providing excellent performance in high temperature applications.



**Do not mix oil types, weights or brands.**



Normal break-in period of **LAPLANTE** air compressors is 25 hours.

for the first 500 hours of compressor operation, a careful and regular check of the oil level should be made. Maintain oil level at the full time.

**Change To Synthetic Lubricant**

If changing to synthetic lubricant, the following steps must be completed.

Compressor must run for a 25 hour break-in period using LAPLANTE ISO 100 oil.

Thoroughly drain existing oil from crankcase.

Fill crankcase with a full charge of synthetic lubricant.

Run compressor for 200 hours.

Stop compressor and thoroughly drain the synthetic lubricant.

Add a full charge of synthetic lubricant.

Compressor now ready to run for extended period before next lubricant change made. Maintain oil level at the full line.

**Lubricant**

**Frequency Of Oil Change**

Change oil every 3000 operating hours whichever comes first. For constant run applications in daily use or units subjected to extremely heavy use change oil monthly.

#### **Oil Recommendation**



**Any Approved Oil Which Is Equal To Those Specified May Be Used**

**Ambient Or Room Temperature 55° F To 120° F**

| AMOCO | SHELL                           | MOBIL                     | TEXACO     | CHEVRON | GULF         | EXXON         |
|-------|---------------------------------|---------------------------|------------|---------|--------------|---------------|
| #51   | Tellus Oil 41 Rotella<br>Oil 30 | Del vac 1230<br>DTE Heavy | Regal ER&O | EP68X   | Paramount 58 | Teresstic 100 |

**Ambient Or Room Temperature 32° F TO 55° F**

| AMOCO | SHELL                               | MOBIL                         | TEXACO       | CHEVRON | GULF         | EXXON        |
|-------|-------------------------------------|-------------------------------|--------------|---------|--------------|--------------|
| #31   | Tellus Oil 33 Rotella<br>Oil 20-20W | Delvac 1220<br>DTE Heavy Med. | Regal CR & O | EP55X   | Paramount 49 | Teresstic 68 |

**Ambient Or Room Temperature 0° F TO 32° F**

| AMOCO | SHELL                            | MOBIL                     | TEXACO    | CHEVRON | GULF         | EXXON        |
|-------|----------------------------------|---------------------------|-----------|---------|--------------|--------------|
| #21   | Tellus Oil 25 Rotella<br>Oil 10W | Delvac 1210<br>DTE Medium | Cetus Oil | EP45X   | Paramount 65 | Teresstic 32 |

**Suction Filter**

Regularly and carefully maintain the suction filter approx. every 500 operating hours, depending on the degree of soiling of the air taken in. Soiled suction filters can cause high oil consumption and reduced delivery quantity! If the installation site is heavily contaminated with dust, provide a dry air filter with paper cartridge. If the ambient air is heavily contaminated, we recommend using dry air filters.

All compressors are available with a common air filter with under pressure display for all cylinders.

**Clean air filter**

Nearly 1500 operating hours or 1 year

Check air filter and clean, if necessary

After undoing the snap fasteners, lift the cover off and take out the filter cartridge. If the filter is soiled, clean as follows:

Clean the cartridge on the outside by an inclined air blast at max. 3-5 bar.

The cartridges can be cleaned up to three times before being replaced with new ones.

Nearly 1500 operating hours or 1 year to change the filter element

**Clean the filter casing.**

Carefully inspect the cartridge for damage. Only use completely intact filters cartridges!

Examine cover seal and replace with a new one if damaged.

Insert filter cartridge, replace casing cover and close with fastening clamps.



Cleaning the air filter

### Maintenance intervals

We recommend servicing and maintaining your compressor at the following intervals. The hours of operation refer to average working conditions. Other intervals may apply depending on these conditions. Please contact LAPLANTE in this event.



Please record each maintenance task in the table on the last pages of these instructions! This may help **LAPLANTE-Service** to locate faults if any occur.

| Maintenance work                                  | Maintenance intervals dependent on usage |                  |               |
|---|--|------------------|---------------|
|   | either after                             | or               |               |
|   | Operating hours                          | weekly / monthly | yearly        |
| Check oil level and top up, if necessary          |  | weekly           |               |
| Check suction filter and clean, if necessary      | 500                                      | monthly          |               |
| Replace suction filter cartridge                  | 2000                                     |                  | X             |
| Check safety valve                                | 2000                                     |                  | X             |
| Check cooler for soiling and clean, if necessary  | 500                                      | monthly          |               |
| Change oil *                                      | 1.000                                    |                  | every 1 years |
| Check V-belt for damage and replace, if necessary | 2.000                                    |                  | X             |

## List of Maintenance and service work

[illegible]

[illegible]



[illegible]

[illegible]

[illegible]

## Instruction Manual of NEMA Motors

Carefully read and fully understand the Owner's Manual Prior to installation, operation and maintenance of your motor.

### 1. RECEIVING AND INSPECTION

Check packing list and inspect the motor to make sure no damage has occurred during shipment. Turn the motor shaft by hand to be certain that it rotates freely without any mechanical rubbing or other audible noise. Check the nameplate for conformance with power supply and control equipment requirements.

### 2. STORAGE



**FALLING EQUIPMENT can injure or death**

**Lift only using equipment of adequate lifting capacity.**

**If so equipped, use lift ring(s) on the motor to lift ONLY the motor and mounted accessories**

Motor stock areas should be clean, dry, vibration free and have a relatively constant ambient temperature. For added bearing protection while the motor is in storage, turn the motor shaft every six months.

Windings should storage, the resistance reading must not have dropped more than 50% from the initial reading. All external motor parts subject to corrosion, such as shaft and other machined surfaces, must be protected by applying a corrosion-resistant coating.

### 3. INSTALLATION

For maximum motor life, place the motor in a clean, dry, well-ventilated location easily accessible for inspecting, cleaning and lubricating.

#### 3.1 INSTALLATION- MECHANICAL



**MOVING PARTS can injure.**

Before starting the motor, be sure the shaft key is captive.

Consider the application and provide guarding to protect personnel.

**Base**

Mount the motor on a firm foundation or base sufficiently rigid to prevent excessive vibration.

If necessary, properly shim the motor to prevent undue stress on the motor frame and for better alignment of the unit.

**Drive**

The pulley, sprocket, or gear used in the drive should be located on the shaft as close to the shaft shoulder as possible. Belt Drive: Align the pulleys so that the belt(s) will run through.

Properly tension the belt; excessive tension will cause premature bearing failure.

Chain Drive: Align the sprockets so that the chain will run through. Avoid excessive chain tension. Gear Drive and Direct Connection: Accurate alignment is essential. Secure the motor and driven unit rigidly to the base. Shims may be needed to achieve proper alignment.

**3.2 INSTALLATION-ELECTRICAL****ELECTRIC SHOCK can kill.**

Disconnect input power supply before installing or servicing motor. Motor lead connections can short and cause damage or injury if not well secured and insulated. Use washers, lock washers and the largest bolt size which will pass through the motor lead terminals in making connections. Insulate the connection, equal to or better than the insulation on the supply conductors. Properly ground the motor-See Grounding. Check power supply to make certain that voltage, frequency and current carrying capacity are in accordance with the motor nameplate. Proper branch circuit supply to a motor should include a disconnect switch, short circuit current fuse or breaker protection, motor starter (controller) and correctly sized thermal elements or overload relay protection. Each of these should be properly sized and installed per the National Electrical Code and local codes.

**Terminal Box**

Remove the appropriate knockout. For terminal boxes without a knockout, either a threaded power-conduit entry hole is provided or the installer is responsible for supplying a correctly sized hole.

**Motor Connection**

See the nameplate.

## GROUNDING



**ELECTRIC SHOCK can kill.**

**Connect the motor frame to a good earth ground per the National Electrical code and local codes.**



Motors may be electrically connected to earth ground using a terminal box mounting screw or a separate grounding screw when provided. In making the ground connection, the installer should make certain that there is a good electrical connection between the grounding lead and the motor

## 4. OPERATION

Power supply ratings conform to the requirements on nameplate, after checking that the shaft key is secure, operate the motor free of load and check the direction of rotation. If the motor rotates in the wrong direction, interchange any two supply leads.

Couple the motor to its load and operate it for a minimum of one hour. During this period, check for any unusual noise or thermal conditions check the actual operating current to be sure that the nameplate current times service factor is not exceeded for steady continuous loads.

## 5. MAINTENANCE



**ELECTRIC SHOCK can kill.**

Internal parts of the motor may be at line potential even when it is not rotating.

Disconnect all input power to the drive and motor before performing any maintenance.

Do not touch by hand the frame of working motor to prevent from being scalded.

Periodically inspect the motor for excessive dirt, friction or vibration. Dust may be blown from an inaccessible location using compressed air. Keep the ventilation openings clear to allow free passage of air.

**BEARING SYSTEM**

Motors have a high quality, premium design bearing system. Bearing sizes and enclosures are identified on most motor nameplates. The majority are double-shielded, deep-groove ball bearings. Double-sealed ball bearings are also used.

**Check valve**

The check valve closes when the compressor stops operating, preventing air from flowing out of the tank through the pressure release valve. After the compressor stop operating, if air continues to escape through the release valve, it is an indication that the check valve is leaking. This can be corrected by removing check valve and cleaning disc and seat. If check valve is worn badly, replace same.



Before removing check valve be sure all air is drained out of tank and power is disconnected. Failure to do so may result in injury or equipment damage.



## Air Receiver

### General

Install the compressed air receiver such that nobody is endangered. Protect it from mechanical influences in as much that damage entailing dangerous consequences for persons is not be expected. Ensure that it is possible to operate the compressed air receiver and its equipment from a safe workplace.



Maintain the protection areas and protection space!

### Safety information

Ensure that the compressed air receiver is securely mounted and cannot be displaced and tilted by external forces. This also includes the additional weight of the test medium during pressure testing! Where possible, ensure that the receiver is accessible from all sides for repetitive tests. Ensure that the company plate is easily visible.

It is forbidden to undertake repair and modification work which may influence the safety of the compressed air receiver. This applies in particular to work which may change the material properties. Do not undertake welding work on a receiver once the water pressure tests have been passed! Reinforcing plates for mounting plates and brackets are not considered as pressure bearing elements.



Suitable protect compressed air receiver against corrosion.

Adhere to the generally accepted rules of technology when maintaining and installing the receiver.

### Checking the safety valve



The safety valve must respond when the compressor pressure increases too high.

The inter stage pressure relief valve is provided to protect against inter stage over pressure and is factory set for maximum pressure of 175 PSIG. If the pressure relief valve pops open, it indicates trouble. Shut down the unit immediately and determine and correct the malfunction. Inspect the head valves. Serious damage can result if not corrected and can lead to complete destruction of the unit. Tampering with the inter stage pressure relief valve, or plugging the opening destroys the protection provided and voids all warranty.

The valve must be able to blow off the entire delivery quantity of the compressor. As it is rarely or never operated, it is of utmost importance for the safety of the compressor that the valve is regularly checked. Check the valve once a year or after 2000 operating hours.

This is the only maintenance work which has to be performed while the compressor is running. Make sure that all safety devices are correctly installed! Never perform this work with the safety device removed!



Danger of injury or death!



### **Do not readjust!!**

Test safety valve on tank:

A ring is located at the free end of the safety valve. Pull the ring by hand. Never remove the lead seal at the head of the valve!

If you now pull the ring further, the safety valve should blow off increasingly more air.

If the valve blows off correctly, drop hand tight in its seating and complete the check.

- If the valve does not blow off although you have pull the ring up to the end of the stud, it is defective. Please have a new safety valve fitted by **LAPLANTE** Service.

### **Condensate**

#### **Manually draining off condensate from the compressed air receiver**

If no automatic condensate separator is fitted, drain off the condensate by hand at least once a week.



Depressurize the receiver.

Place a suitable collecting basin underneath the ball valve under the receiver.

Open the ball valve and allow the condensate to drain off into the collecting basin.

Once the condensate has completely drained off, close the ball valve again and correctly dispose of the condensate.

## Safety information



**Please observe the following instructions when performing any maintenance, cleaning, repair work; when relocating the compressor plant; prior to installing and dismantling component parts, receivers, fittings and screw connections.**

- **Always isolate the compressor at the main switch prior to performing any maintenance work.**  
**Secure the main switch against accidental switching on! Remove the electrical fuses in order to avoid accidents!**
- **Depressurize the compressor!**  
**Disconnect from the compressed air network by closing the ball valve on the compressed air outlet.**
- **Perform maintenance or servicing work.**
- **Only allow skilled and qualified welders to perform welding work on compressed air receivers!**  
**After welding work on compressed air receivers, new constructional and hydrostatic pressure tests are to be carried out.**
- **Prior to switching on again, check whether anyone else is working on the compressor!**

**For your own safety, never omit a safety step!**

**Otherwise you will risk injury from restarting, electric shock or parts which may fly off!**

### **Check V-belts for damage and replace with new ones, if necessary**

The belts should be checked for damage and wear after every 2000 hours or once yearly.

- Remove the belt guard
- Turn the belts slowly using the fan wheel.
- Check - in addition to foreign bodies- for large eruptions in the flanks of the belts and for tears in the fabric indicating the belt is becoming brittle.

### **If it is necessary to change the belts, proceed as follows:**

- Unscrew the four retaining screws with a suitable spanner from the slots in the motor plate.
- Completely slacken the V-belts. Turn the tensioning block using the spanner.
- Remove the belts from the pulleys and clean, if necessary.
- Check the flanks of the pulleys and clean, if necessary.
- Fit new V-belts. Only change the belts as a complete set, never individually!
- Retension the V-belts: Turn the tensioning spindle clockwise until achieving the correct belt tension, i.e. when a testing force of 30 N applied vertically to the belt between drive and flywheel causes the belts to sag by approx. 10 - 12 mm.
- After setting the correct belt tension, screw the motor plate firmly in place and replace the belt guard.

## Magnetic Starter

### Safety information



Please observe the following instructions when performing any maintenance, cleaning, repair work; when relocating the compressor plant; prior to installing and dismounting component parts, receivers, fittings and screw connections.

- Always isolate the compressor at the main switch prior to performing any maintenance work.  
Secure the main switch against accidental switching on! Remove the electrical fuses in order to avoid accidents!
- Depressurize the compressor!  
Disconnect from the compressed air network by closing the ball valve on the compressed air outlet.
- Perform maintenance or servicing work.
- Only allow skilled and qualified welders to perform welding work on compressed air receivers!  
After welding work on compressed air receivers, new constructional and hydrostatic pressure tests are to be carried out.
- Prior to switching on again, check whether anyone else is working on the compressor!

For your own safety, never omit a safety step!

Otherwise you will risk injury from restarting, electric shock or parts which may fly off!



### General


- 1.1 Turn off power before carrying out any maintenance.
- 1.2 Please handle carefully and avoid abnormal vibration and shock.
- 1.3 Operational Temperature: -5°C~55°C.  
Storage Temperature I -40°C~70°C; Relative Humidity: 45-65%.
2. Installation and wiring:
  - 2.1 Ensure that specification (rated voltage and power, voltage and frequency of operation)
  - 2.2 Select appropriate conductor and tighten with appropriate torque with right tool. Connect with diagram connection inside box cover, if not fit .contact us.

2.3 Tightening torques for elements are given below:

| Type                         |                           | CU-11/16 | CU-18/23 | CU-27/32/38<br>CU-40 | CU-50/65/80 | RHN-10 | RHN-80 |
|------------------------------|---------------------------|----------|----------|----------------------|-------------|--------|--------|
| Main Terminal                | screw./blot               | M3.5     | M4       | M5                   | M6          | M4     | M5     |
| Aux. contact & Coil terminal | Kgf .cm tightening torque | 6.5-10   | 10-15    | 20-30                | 35-50       | 10-15  | 20-30  |
|                              | screw./blot               | M3.5     | M3.5     | M3.5                 | M3.5        | M3.5   | M3.5   |
|                              | Tightening torque         | 6.5-10   | 6.5-10   | 6.5-10               | 6.5-10      | 6.5-10 | 6.5-10 |

Tightening torque shall be within the values given above to avoid deteriorating the screws.

2.4 Mounting position shall be within the ranges specified below :



Vertical

Vertical

2.5 Ensure that the starter can be operated normally.

### 3. Countermeasures for normal malfunctions:

| Malfunction             |   | Causation       |                     |                                  |  |  |                                  |                                  |                                  |                                  |                                  | Countermeasures                                      |
|-------------------------|---|-----------------|---------------------|----------------------------------|--|--|----------------------------------|----------------------------------|----------------------------------|----------------------------------|----------------------------------|--|
|                         |   | The fuse breaks | The motor burns out | The temperature of the tip raise | The heater set of the thermal overload relay fuses | The thermal overload relay can not trips | The thermal overload relay trips | The thermal overload relay trips | The thermal overload relay trips | The thermal overload relay trips | The thermal overload relay trips |  |
| power                   | The fuse breaks                               | •               |                     |                                  | •  |  |                                  |                                  |                                  |                                  |                                  | Research and change the fuse                         |
|                         | Molded Case Circuit breaker trips             | •               |                     |                                  | •  |  |                                  |                                  |                                  |                                  |                                  | Research and reset                                   |
|                         | Voltage falls                                 | •               | •                   |                                  | •  |  | •                                |                                  |                                  |                                  |                                  | Check-up the power                                   |
|                         | Voltage is high                               |                 |                     |                                  |  |  |                                  |                                  |                                  |                                  | •                                | Check-up the power                                   |
| contactor               | contactor tip is dirty                        |                 | •                   |                                  |  |  |                                  |                                  |                                  |                                  |                                  | Clean the contactor tip with the bumf                |
|                         | Coil breaks                                   | •               |                     |                                  |  |  |                                  |                                  |                                  |                                  |                                  | Chang a new one                                      |
|                         | Layer short of Coil                           | •               |                     |                                  |  |  |                                  |                                  |                                  |                                  |                                  | Chang a new one                                      |
|                         | SH coil breaks                                |                 |                     |                                  |  |  |                                  |                                  |                                  |                                  |                                  | Change the contactor                                 |
|                         | The lipin on the contact tip                  |                 |                     |                                  |  |  | •                                | •                                |                                  |                                  | •                                | Clean but can't use menstruum                        |
|                         | Contact tip fues                              |                 |                     | •                                |  |  |                                  |                                  |                                  |                                  |                                  | Chang all contact tips                               |
|                         | Arc horn breaks way or unlocked               |                 |                     |                                  |  |  | •                                | •                                |                                  |                                  |                                  | Change a new production or lock the arc chamber room |
| Mechanism of the        | Rectifier burns out                           | •               |                     |                                  |  |  |                                  |                                  |                                  |                                  |                                  | Chang a new one                                      |
|                         | The mechanism is dirty                        |                 |                     |                                  |  |  | •                                |                                  |                                  |                                  |                                  | Unpick and wash, select dustproof type               |
|                         | The core is dirty                             |                 |                     |                                  |  |  | •                                | •                                |                                  |                                  |                                  | Unpick and wash without lipin                        |
|                         | Abrasion of core                              |                 |                     | •                                |  |  |                                  |                                  |                                  |                                  |                                  | Chang a new one                                      |
| Thermal over relay load | Phenolic part breaks                          | •               |                     | •                                |  |  |                                  |                                  |                                  |                                  |                                  | Chang a new one                                      |
|                         | The current set wrong                         |                 |                     |                                  |  |  | •                                | •                                |                                  |                                  | •                                | Set by the current designation of motor              |
|                         | The heater set fuses                          |                 |                     |                                  |  |  | •                                |                                  |                                  | •                                |                                  | Research and change a new one                        |
|                         | The thermal overload relay trip               | •               |                     |                                  |  |  |                                  |                                  |                                  |                                  |                                  | Research and reset                                   |
|                         | The thermal overload relay trip time is wrong |                 |                     |                                  |  |  | •                                | •                                |                                  |                                  | •                                | Change a new one                                     |

|           |                                   |   |  |  |  |   |   |   |   |  |   |  |  |  |  |   |
|-----------|-----------------------------------|---|--|--|--|---|---|---|---|--|---|--|--|--|--|---|
| Condition | High temperature                  |   |  |  |  |   |   |   | • |  |   |  |  |  |  | Select the compensation temperature type                        |
|           | The condition is abominable       | • |  |  |  | • | • | • |   |  |   |  |  |  |  | Select water-repellent, fireproof or rot proof type ;           |
|           | The voltage of coil mistake       | • |  |  |  | • |   |   |   |  |   |  |  |  |  | Change the coil   |
|           | The operating rate is high        |   |  |  |  | • | • | • | • |  |   |  |  |  |  | Review selected capacitance                                     |
|           | The motor starts late             |   |  |  |  |   |   |   | • |  |   |  |  |  |  | Select the thermal overload relay which can start for long time |
|           | The capacities of motor unfit     |   |  |  |  |   |   |   | • |  |   |  |  |  |  | Research and change a advisable motor                           |
|           | Short circuit of motor            |   |  |  |  | • |   |   |   |  | • |  |  |  |  | Research and obviate the malfunction                            |
|           | The capacities of contactor unfit |   |  |  |  | • | • | • | • |  |   |  |  |  |  | Select fit capacitance  |
|           | The connect mistakes              |   |  |  |  | • |   |   |   |  | • |  |  |  |  | Research and deal with it                                       |